

User Manual

Please read this user manual carefully before using this product.

JPS-008A Specification
Ultrasonic power: 35W
Ultrasonic frequency: 42kHz
Capacity: 800ml
Timer: 180s/300s/480s (3)
Tank size: 150*85*65mm
Power supply: AC220V-240V 50Hz/AC110V-120V 60HZ
Tank material: SUS#304

Foreword

Dear users:

Thank you for using our products. In order to use the machine correctly, please read the user manual carefully before using and keep them in a safe place for future reference.

Special note

1. All contents in this manual have been carefully checked. If there are any printing errors or misunderstandings, please contact us. 2. The product is subject to update without prior notice.

Applications

This product is widely used in machinery, electronics, electrical appliances, telecommunications, hardware, medical, semiconductor, watch and jewelry, optics, glasses, chemical, textile printing and dyeing, automotive, marine, aviation, industrial and mining, etc.

Precautions

1. It is forbidden to start without the cleaning liquid in the tank, which may cause damage to the machine;
2. It is forbidden to start the machine before adding water;
3. It is forbidden to hit the bottom of the cleaning tank with heavy objects, causing damage to the

wafer;

4. It is strictly forbidden to use alcohol, gasoline or any flammable gas as a solution adding to the washing machine.

5. It is strictly forbidden to work near heat sources and in humid environments;

Routine maintenance

1. The cleaning machine should add enough cleaning liquid (more than 1/3 of the container) during using.
2. Do not place the work-piece on the bottom of the cleaning tank during cleaning, please use professional cleaning basket;
3. Regularly blow off dust on the electrical control part with high-pressure wind;
4. Regularly clean the cleaning tank to keep the cleaning tank clean;

In order to extend the life of the machine, please stop using the machine for a while after 30 minutes working.

Operation guide

Step 1: Add the right amount of cleaning solution in the cleaning tank.

Step 2: Connect the power plug correctly (back of the machine), please make sure the machine power is reliably grounded! The digital display light is on at this time.

Step 3: Press "TIME" to set the time and press "ON/OFF" button, L1 light is on at this time and the machine performs ultrasonic work until the countdown ends.



User Manual

Please read this user manual carefully before using this product.

JPS-008A Specification
Ultrasonic power: 35W
Ultrasonic frequency: 42kHz
Capacity: 800ml
Timer: 180s/300s/480s (3)
Tank size: 150*85*65mm
Power supply: AC220V-240V 50Hz/AC110V-120V 60HZ
Tank material: SUS#304

Foreword

Dear users:

Thank you for using our products. In order to use the machine correctly, please read the user manual carefully before using and keep them in a safe place for future reference.

Special note

1. All contents in this manual have been carefully checked. If there are any printing errors or misunderstandings, please contact us. 2. The product is subject to update without prior notice.

Applications

This product is widely used in machinery, electronics, electrical appliances, telecommunications, hardware, medical, semiconductor, watch and jewelry, optics, glasses, chemical, textile printing and dyeing, automotive, marine, aviation, industrial and mining, etc.

Precautions

1. It is forbidden to start without the cleaning liquid in the tank, which may cause damage to the machine;
2. It is forbidden to start the machine before adding water;
3. It is forbidden to hit the bottom of the cleaning tank with heavy objects, causing damage to the

wafer;

4. It is strictly forbidden to use alcohol, gasoline or any flammable gas as a solution adding to the washing machine.

5. It is strictly forbidden to work near heat sources and in humid environments;

Routine maintenance

1. The cleaning machine should add enough cleaning liquid (more than 1/3 of the container) during using.
2. Do not place the work-piece on the bottom of the cleaning tank during cleaning, please use professional cleaning basket;
3. Regularly blow off dust on the electrical control part with high-pressure wind;
4. Regularly clean the cleaning tank to keep the cleaning tank clean;

In order to extend the life of the machine, please stop using the machine for a while after 30 minutes working.

Operation guide

Step 1: Add the right amount of cleaning solution in the cleaning tank.

Step 2: Connect the power plug correctly (back of the machine), please make sure the machine power is reliably grounded! The digital display light is on at this time.

Step 3: Press "TIME" to set the time and press "ON/OFF" button, L1 light is on at this time and the machine performs ultrasonic work until the countdown ends.

